

1. Insertion Tube Plug
2. Battery Cover Button
3. Brightness
4. Status Light
5. Power / Plug / Charge
6. Power On/Off
7. ESC Key
8. Upward Key
9. Downward Key
10. OK Key
11. Video Key
12. Still Key
13. Reset
14. TV Out Jack
15. Mini USB Jack
16. DC In Jack

