

Inspection Video Scope

Under the preview mode, press the OK key to show MENU (Fig 1) as below.

The definitions are:

- Video Output
- Video Format
- Date/Time Setup
- Language
- Delete All
- Auto Power off
- Mirror Mode




1. Video Output (Fig 1)

Plug the AV cable into the TV out jack on the right side of the machine. Press OK key to open the menu. Press ▲/▼ key to select "Video Output" then press "OK" key to link to the external monitoring device, meanwhile the machine screen is off. Executing this command again to end this function. This output function will automatically detect whether the AV cable is in the "TV out" jack or not. If execution of this function is under unsuccessful linkage, it will switch the signal back to the machine screen automatically.

Inspection Video Scope

2. Video Format

Under MENU mode, select "Video Format" and press OK key to start "TV Output" (Fig 2). Press ▲/▼ key to select NTSC or PAL, then press OK key to decide. The system will enter into "FACTORY SETUP" automatically for more detailed settings.



FACTORY SETUP

On the page of FACTORY SETUP (Fig 3), press ▲/▼ key to select items, press OK key to enter into the detailed image setup, press ▲/▼ key to adjust the item value.

Press any of OK / ESC / key to save the value.

Under "FACTORY SETUP", the item value definition is shown as below:

- BRIGHTNESS: To adjust the illumination
- CONTRAST: To adjust contrast (distinguish between light and dark) of the objects
- HUE: To adjust difference in color
- SATURATION: To adjust the value of saturation (color depth)
- DEFAULT: Back to original system settings

