





## Inspection Video Scope

### Key Functions

Button	Under the Preview Mode	Under the Surfing Mode	Under the Menu Mode
 (Upward Key)	N/A	Back to the previous photo or video	Move the selection to the upper one
 (Downward Key)	N/A	Go to the next photo or video	Move the selection to the lower one
<b>OK</b>	To enter the menu mode	Delete the photos or videos	To execute the selected function
<b>ESC</b>	To enter the surfing mode	Back to the preview mode	Back to the surfing mode
 Still Key	To take photos	Back to the preview mode	Back to the preview mode (The model version will be shown on the screen for 2 secs.)
 Video Key	To start / end recording video	Press the button to play the video and press again to pause the video	Back to the preview mode



## Inspection Video Scope

### Operating in Modes

#### Preview Mode

1. This mode runs under a real-time monitoring condition. The target is shown on the screen while the lens is aiming on it.  
Monitoring, image taking and video shooting are operated under this mode.
2. It enters the preview mode automatically after photos or videos are taken (power on and mode shifting will be in preview mode automatically).
3. It shows the condition of the battery and the time. It shows "no card" on the screen if there is no SD card in.

#### Surfing Mode

1. It is used to check the photos and videos in the SD card and provide the deletion function of a single file.
2. The type of files is shown on the down-left corner of the screen. The icon of photos is  , videos is 

#### Menu Mode

File deleting, machine setting and other related adjustment.

#### USB Mode

Please refer to page 15 "Data Access Management"