


5. Delete a Single file (In Surfing Mode Only)

Under Preview Mode, press ESC key to enter into Surfing Mode, with ▲/▼ key to find the file to delete, press OK key to open the DELETE function (FigD). With ▲/▼ key to select YES (delete file) or NO (keep file) or press ESC key to leave the page.



Inspection Video Scope

USB MODE

Connect the USB cable from computer USB terminal to the machine mini USB jack and the system will activate USB mode automatically (Fig E). Under this mode, the computer can access the photos and videos saved in the SD card.

Use the attached SD card as the standard accessory. All the photos and videos are saved in [100DSCIM] file folder under [DCIM] main folder. Files are named by sequential numbers. All photos and videos have the same naming rule but different in filename extensions (.jpg for photos and .avi for videos).

USB MODE

Fig E

The data folder structure is showed as below figures.

