




3. Recording Videos

Under "Preview Mode", press  key to start recording. There will be a symbol ● appeared on the bottom of the screen as the function starts (see below picture). The recording time will be shown in red on the upper-right corner of the screen. Press any key to end the recording.









Note: Photos or videos can not be made while there is no SD card in the machine.

4. Viewing Files in Surfing Mode

Under "Preview Mode", press ESC key to enter into Surfing Mode. System will start displaying the saved files from the latest taken photos or videos, then with  key to view other image files (as shown in Fig A for Photos, Fig B for Videos, icon shown on the lower-left corner of the screen). Press  to play video files.

During Video Playing:

1. Press any of  /  / OK key to pause the video (Fig C), press  key to resume the play, or press any of ESC /  /  to switch back to Surfing Mode from the pause.
2. Press  key to switch back to Surfing Mode.

For photo files, shooting time will be shown in yellow on the lower-right corner of the screen.

